


HOW TO USE THE IRON

1. Hang bottle 2 meters above pressing surface.
(See Use Instruction)
2. Connect the silicone hose to the end of solenoid valve & to the end of water bottle valve. (See Use Instruction)
3. Tie the electrical cord and silicone hose together using S type plastic holder.
4. Plug the iron cord into grounded electrical outlet, and main switch on.
5. Set the temperature dial on NO. 4 and let the iron heat up for ten minutes.
6. Open the bottle valve and allow the hose to fill with water by pressing the steam switch. The iron is now ready for use.
7. When not pressing, place the iron on the supplied iron rest.
8. Always unplug the iron when unattended or not in use.

IMPORTANT NOTICE


Do not stand iron on its back.



ABOUT DEMINERALIZER:

The demineralizer extends the life of the iron & prevents calcium build-up. When the demineralizer changes from blue to brown, replace it by ordering a new package from your distributor.

As you want to use demineralizer, you put one pack of it to the water bottle & use iron.



INSTRUCTION

Now that your iron is properly set-up, please read the following tips for pressing with professional results,:

- ▶ Initially, to allow water to enter into the iron, press the steam switch. This may take a few seconds, then you will see steam.
- ▶ Begin to press.
- ▶ For best results, it is only necessary to press the steam switch for a few seconds at a time. It is not necessary to activate switch continuously.
- ▶ There are several settings on your temperature dial. Recommended temperature settings are as follows:

#1,2	-Preheat
#3	-Silk and delicate fabric(low temperature)
#4	-Cotton and wool(medium temperature)
#5	-Linen, yarn & thick fabric(high temperature)

- ▶ A teflon shoe is recommended to prevent garment shine and starch build-up and is available from your distributor
- ▶ While operating iron, it must be very hot, So, you must put it on the silicone iron rest When you are not use it. Also, Do not put anything to burn easily beside.
- ▶ When unattended or not in use, always turn off and unplug your iron.

SAFETY INSTRUCTION

1. Before using iron, make sure your voltage corresponds to the voltage of iron and plug it into outlet.
2. Fill up water tank with clean water.
3. Do not press valve operating switch for a long time. It can cause water's leaking.
4. If the temperature of iron keep going up, stop using iron and contact Service Center for repair or the store you purchased.
5. If the appliance shows any defect, stop using it and contact Service Center for repair or the store you purchased.
6. While using, keep any parts of body away the soleplate of iron. Burns can occur from touching hot metal parts.
7. While using, do not jet steam towards any parts of body. Burns can occur from touching hot water, or steam.
8. Contact an authorized service facility only for repair and information on examination.