CONTROL PANEL QUICK START GUIDE FOR MODEL:
7360RB-7DD-1 Full Automatic Function Machine

Factory Reset   Control Buttons   Parameters *(Refer to Owners Manual)*

Saving Parameters
(Refer to Owners Manual)

Digital Display

A B C D
E F G H

A E ① = Normal Stitching   P1/P15 ② = Sequential Stitch Count
③ = Single Stitch Count

B ① = Soft Start   ② = ON: Fixed speed
Auto full count
③ = OFF: Variable speed
Auto full count

C ① = Auto Foot Up   ② = Auto Foot Up, Thread Trim
③ = Auto Foot Up, Thread Trim and Foot Up After Trim

D Begin Auto Back Tack
ABAB ① = Half Tack ② = Full Tack ③ = Double Tack

E ABABCD ① = Bar Tack   EFGH ② = Box Tack

F ① = Thread Tuck   O = Off ② = Thread Tuck   1 = On
T ③ = Teaching Mode, Repeat Stitch Count

G ① = Auto Thread Trim   ② = Needle Up *or* Needle Down

H Finish Auto Back Tack
DCDC ① = Half Tack ② = Full Tack ③ = Double Tack

Notes on parameters settings:

Press and hold "P".
Scroll to desired number.
Set parameter desired values.
Press "S" to set
Press "P" to exit

Most common parameters adjusted:

001 max speed
004 fwd back tack speed
005 rev back tack speed

Additional Features

Light switch

Half Step (jog stitch)

Reverse (for jog stitch)

Thread Clamp